

Declaration of Conformity

We, Manufacturer/Importer

AirLive Technology Corporation
4F, No.132, Lane 235, Baoqian Rd., Xindian Dist.,
New Taipei City 23145, Taiwan

Declare that the product

28 Ports Multi Giga L3 Managed PoE+ Switch, 400W
L3POE-XGS2404-400

28 Ports Multi Giga L3 Managed Switch
L3-XGS2404

52 Ports Multi Giga L3 Managed PoE+ Switch, 600W
L3POE-XGS4804-600

52 Ports Multi Giga L3 Managed Switch
L3-XGS4804

28 Ports Multi Giga Fiber L3 Managed Switch
L3-XGF28

is in conformity with

In accordance with 2014/30/EU and 2014/35/EU Directive

Clause	Description
■ EN 55032:2015	Electromagnetic compatibility (EMC)
■ EN 62368-1	Electromagnetic compatibility (LVD)

■ CE marking



Manufacturer/Importer

Name : A van Rossem Position/ Title : Product Manager
Place : Republic of China (Taiwan) Date : May 2022



L3POE-XGS2404-400 / L3-XGS2404



L3POE-XGS4808-600 / L3-XGS4804



L3-XGF28

Regulatory Approvals

● CE Statement

This product complies with the 2014/30/EU and 2014/35/EU directives, including the following safety and EMC standards:

- EN 55032:2015+A11:2020
Electromagnetic compatibility (EMC)
- EN IEC 61000-3-2:2019
Electromagnetic compatibility (EMC)
- EN 61000-3-3:2013+A1:2019
Electromagnetic compatibility (EMC)
- EN 55035:2017+A11:2020
Electromagnetic compatibility (EMC)
- EN 62368-1:2014+A11:2017
Electromagnetic compatibility (LVD) - Safety

● CE Marking Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

● FCC 47 CFR Part 15 Subpart B (Class A), ANSI C63.4:2014

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

● RoHS Statement


This product complies with RoHS directive 2011/65/EU and amendment Commission Delegated Directive (EU)2015/863.

- IEC 62321-3-1:2013
- IEC 62321-5:2013
- IEC 62321-4:2013+AMD1:2017
- IEC 62321-7-1:2015
- IEC 62321-7-2:2017
- IEC 62321-6:2015
- IEC 62321-8:2017

Installation Steps

A. Desktop installation


Step 1: As shown in picture 1, lay the switch flat on the desktop, and ensure that at least 10cm of space is reserved on both sides of the vent of the switch so that the switch can be well ventilated and cooled.



Picture 1

Wall-mounted installation

Step 1: As shown in picture 2, find the mounting ears and screws from the accessory bag of the machine, then place the switch upright, place the mounting ears to the installation position, and see if the screw holes are aligned properly. After confirming the match, use a screwdriver to fix the hanging ears on both sides of the machine with screws.




Left

Right


Picture 2

B. Rack installation

Step 1: Fix the L-shaped mounting brackets on both sides of the switch with the screws provided in the accessories.



Step 2: The mounting brackets are fixed on the guide groove with screws to ensure that the switch is stable and horizontally installed on the rack.



C. Power Connection

1. Connect the powercord to the back of the Switch and turn the power switch on.

Indicator Description

Indicators	Definition	Status	Description
PWR	Power supply	Lighting	Powered
		Light off	Power failed
SYS	System state	Lighting	system normal
		Light off	system startup
SW /Mode	DIP indicator	Lighting	VLAN
		Shining	Extend
		Light off	Default
Link /1000M	Network Link	Lighting	Link normal
		Light off	Link Disconnected
Link /ACT	Network Link&Data	Lighting	Link normal
		Shining	Data Transmission
		Light off	Link Disconnected
PoE	PoE Supply	Lighting	PoE ON
		Light off	PoE OFF

EN English

Important Information

- The default IP address: **192.168.2.1**
- The default username / password is **admin**
- The content of user's guide and associated software can be downloaded from the website (www.airlive.com)

Installation Step:

1. Connect your device's PoE port to the switch's PoE port
2. Your PoE device should get the power from the switch now. If you want to change settings via web management. Please follow the instructions below.
3. Set your PC's IP address to 192.168.2.50.
4. Open your web browser and enter "192.168.2.1" to get into the switch's web management.
5. Enter "admin" for username, "admin" for password.

ES Español

Información importante

- Default IP: **192.168.2.1**
- Contraseña default: **admin**
- El contenido de la Guía de Usuario y el software asociado puede descargarse desde el sitio web (www.airlive.com)

Pasos de instalación:

1. Conecte el puerto PoE de su dispositivo al puerto PoE del switch .
2. En este momento su dispositivo PoE debe recibir energía desde el switch. Si usted desea cambiar los parámetros vía web, por favor siga las siguientes instrucciones.
3. Configure la dirección IP de su PC en 192.168.2.50.
4. Abra su navegador web e ingrese "192.168.2.1" para acceder al administrador web del switch.
5. Ingrese "admin" como nombre de usuario, "admin" como contraseña

DE Deutsch

Wichtige Information

- Die voreingestellte IP Adresse: **192.168.2.1**
- Das voreingestellte Passwort lautet **admin**
- Das Benutzerhandbuch und die benötigte Software kann auf unserer Webseite (www.airlive.com)

Installationsschritte:

1. Verbinden Sie den PoE Port ihres Gerätes mit dem PoE Port vom Switch.
2. Ihr PoE Gerät sollte jetzt den Strom vom Switch beziehen. Wenn Sie Einstellungen via Webbrowser ändern möchten, dann folgen Sie bitte den unten angegebenen Schritten:
3. Stellen Sie die IP des PC's auf 192.168.2.50.
4. Öffnen Sie ihren Browser und geben "192.168.2.1" ein. Die gelangen zur Web-Management Oberfläche.
5. Geben Sie "admin" als Benutzernamen und "admin" als Passwort ein.

PT Português

Informação Importante

- O endereço IP padrão: **192.168.2.1**
- A palavra-chave padrão é **admin**
- O conteúdo do guia do utilizador e software associado podem ser carregados através do website (www.airlive.com)

Pasos de Instalação:

1. Conecte a porta do seu dispositivo PoE à porta POE do switch
2. Seu dispositivo PoE deve obter agora a energia através do switch. Se desejar alterar as configurações através do gestor web. Siga por favor as instruções em baixo.
3. Defina o endereço IP do seu PC para 192.168.2.50.
4. Abra o seu explorador web e digite "192.168.2.1" para entrar no gestor web do switch.
5. Digite "admin" para o username, "admin" para a password.