Declaration of Conformity

We, Manufacturer/Importer

AirLive Technology Corporation
4F, No.132, Lane 235, Baoqian Rd., Xindian Dist.,
New Taipei City 23145, Taiwan

Declare that the product

Industrial Managed PoE Switch
IGM-1082RBT
is in conformity with

In accordance with 2014/30/EU and 2014/35/EU Directive

Clause	Description
■ **EN 55032:2015**	Electromagnetic compatibility (EMC)
■ **EN 62368-1**	Electromagnetic compatibility (LVD)
■ **CE marking**	CE

Manufacturer/Importer

Name : A van Rossem Position/ Title : Product Manager
Place : Republic of China (Taiwan) Date : May 2024

Regulatory Approvals

- **CE Statement**

  This product complies with the 2014/30/EU and 2014/35/EU directives, including the following safety and EMC standards:

  - **EN 55032:2015+A11:2020**
    Electromagnetic compatibility (EMC)
  - **EN IEC 61000-3-2:2019**
    Electromagnetic compatibility (EMC)
  - **EN 61000-3-3:2013+A1:2019**
    Electromagnetic compatibility (EMC)
  - **EN 55035:2017+A11:2020**
    Electromagnetic compatibility (EMC)
  - **EN 62368-1:2014+A11:2017**
    Electromagnetic compatibility (LVD) - Safety

- **RoHS Statement**

  This product complies with RoHS directive 2011/65/EU and amendment Commission Delegated Directive (EU)2015/863.

  - **IEC 62321-3-1:2013**
  - **IEC 62321-5:2013**
  - **IEC 62321-4:2013+AMD1:2017**
  - **IEC 62321-7-1:2015**
  - **IEC 62321-7-2:2017**
  - **IEC 62321-6:2015**
  - **IEC 62321-8:2017**

- **CE Marking Warning**

  This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

CE AirLive Technology Corporation declares that this device is in compliance with the essential requirements and other relevant provisions of directive 2014/30/EU.

Industrial Managed Gigabit PoE Switch
IGM-1082RBT

www.airlive.com

Quick Setup Guide

Mounting the Switch

A. Din-Rail

1. Screw the DIN-Rail bracket on with the bracket and screws in the accessory kit.
2. Hook the unit over the DIN rail.
3. Push the bottom of the unit towards the DIN Rail until it snaps into place.



B. Wall Mount

1. Un-Screw the DIN Rail bracket from the Switch and attached the wall-mounting plate on the same location with the plate and screws in the accessory kit.



C. Power Connection

1. The DC power interface is a 4-pin terminal block with polarity signs on the top panel.
2. The Switch can be powered from two power supply (input range 48V~55V). The DC power connector is a 4-pin terminal block.



EN English

Important Information

- The default IP address: ***192.168.2.1***
- The default username / password is ***admin***
- The content of user's guide and associated software can be downloaded from the website (www.airlive.com)

Installation Step:

1. Connect your device's PoE port to the switch's POE port
2. Your PoE device should get the power from the switch now. If you want to change settings via web management. Please follow the instructions below.
3. Set your PC's IP address to 192.168.2.50.
4. Open your web browser and enter "192.168.2.1" to get into the switch's web management.
5. Enter "admin" for username, "admin" for password.

DE Deutsch

Wichtige Information

- Die voreingestellte IP Adresse: ***192.168.2.1***
- Das voreingestellte Passwort lautet ***admin***
- Das Benutzerhandbuch und die benötigte Software kann auf unserer Webseite (www.airlive.com)

Installationsschritte:

1. Verbinden Sie den PoE Port ihres Gerätes mit dem PoE Port vom Switch.
2. Ihr PoE Gerät sollte jetzt den Strom vom Switch beziehen. Wenn Sie Einstellungen via Webbrowser ändern möchten, dann folgen Sie bitte den unten angegebenen Schritten:
3. Stellen Sie die IP des PC's auf 192.168.2.50.
4. Öffnen Sie ihren Browser und geben "192.168.2.1" ein. Die gelangen zur Web-Management Oberfläche.
5. Geben Sie "admin" als Benutzernamen und "admin" als Passwort ein.

ES Español

Información importante

- Default IP: ***192.168.2.1***
- Contraseña default: ***admin***
- El contenido de la Guía de Usuario y el software asociado puede descargarse desde el sitio web (www.airlive.com)

Pasos de instalación:

1. Conecte el puerto PoE de su dispositivo al puerto PoE del switch .
2. En este momento su dispositivo PoE debe recibir energía desde el switch. Si usted desea cambiar los parámetros vía web, por favor siga las siguientes instrucciones.
3. Configure la dirección IP de su PC en 192.168.2.50.
4. Abra su navegador web e ingrese "192.168.2.1" para acceder al administrador web del switch.
5. Ingrese "admin" como nombre de usuario, "admin" como contraseña

PT Português

Informação Importante

- O endereço IP padrão: ***192.168.2.1***
- A palavra-chave padrão é ***admin***
- O conteúdo do guia do utilizador e software associado podem ser carregados através do website (www.airlive.com)

Passos de Instalação:

1. Conecte a porta do seu dispositivo PoE à porta POE do switch
2. Seu dispositivo PoE deve obter agora a energia através do switch. Se desejar alterar as configurações através do gestor web. Siga por favor as instruções em baixo.
3. Defina o endereço IP do seu PC para 192.168.2.50.
4. Abra o seu explorador web e digite "192.168.2.1" para entrar no gestor web do switch.
5. Digite "admin" para o username, "admin" para a password.