



How to setup the Sunrise and Sunset Time

You can enable the Sun Rise and Sun Set time from the Settings->Option menu. Once enable, you can use it as a condition in the IF part of the macro.


Step 1: Go to “Settings->Option” menu, then turn open the “Option” menu.




Step 2: From the Option menu, check the box for “Use sunrise and sunset”.




Step 3: From Settings, Click on “Gateway Information” menu, then click on Gateway Time icon.




Step 4: Select your time zone.



Step 5: From Gateway information, click on "Location" icon



Step 6: Click on the Location Icon to input your current location. Then click on okay.



Step 7: Now log out of your APP, then login again. You should see the sunrise and sunset time in the device menu. *If you do not see it, please reboot your gateway.*

