airlive®

POE-GSH2404M-400
400W Managed Gigabit PoE+ switch

Quick Installation Guide

---

1 Login your Switch

Default IP address: 192.168.2.1
Default ID: admin
Default password: admin

---

2 Connect to PC

Please make sure your PC connect into Switch. And setup pc ip address same domain with switch

General

You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.

○ Obtain an IP address automatically
◉ Use the following IP address:

IP address:	192 . 168 . 2 . 5
Subnet mask:	255 . 255 . 255 . 0
Default gateway:	. . .

---

3 Go to Internet

Open your web browser and type
http://192.168.2.1

Login

Username:
Password:

LOGIN

---

4 Login

Login in to web UI and type
ID: admin
Password: admin

airlive®

Status 》 System Information

- Status
  - System Information
  - Logging Message
  - Port
  - Link Aggregation
  - MAC Address Table
- Network

1 3 5 7
2 4 6 8

Go to website for more information.