

Q: Setting up and using the Sunrise and Sunset function.

A: First the Time and Time zone need to be setup correctly, after this the location would need to be entered and the Sunrise & Sunset function can be enabled.


1. Setting up the Time and Time zone in the APP.

Open the Airlive SmartLife Plus APP and select “Settings” from the bottom menu, In the settings page go to “Gateway Information” and click on the two arrows “>>”. Now you will see the Gateway Time information, Click on the “Clock” icon to change the Time settings. First select the NTP Server in the new window, Click on the three “...” and select your NTP Server next click on the Time Zone and select your correct Time Zone and press “OK” when you are done. The correct Time has now been set.



2. Setting up your Gateway Location.

Open the AirLive SmartLife Plus APP and select “Settings” from the bottom menu, In the settings page go to “Gateway Information” and click on the two arrows “>>”. Now you will see the Location information, Click on the balloon icon and a new window will open. On the “Set Location” page again click on the small balloon icon to get your GPS information for Gateway. Once you have the GPS location you can click ok. The correct location has now been set.



3. Turn on Sunrise and Sunset.

Open the AirLive SmartLife Plus APP and select “Settings” from the bottom menu, In the settings page go to “Option” and checkmark Sunrise and Sunset. After this logout of the APP and login again after 30secs now you will see the Sunrise and Sunset option in the Device and Marco page and can use the function.

