www.airlive.com

Declaration of Conformity

We, Manufacturer/Importer

AirLive Technology Corporation
4F, No.132, Lane 235, Baoqian Rd., Xindian Dist.,
New Taipei City 23145, Taiwan

Declare that the product

26 Ports Multi Giga Fiber L3 Managed Data Center Switch
L3D-10XGF26-100GF
is in conformity with

In accordance with 2014/30/EU and 2014/35/EU Directive

L3D-10XGF26-100GF

Clause	Description
■ **EN 55032:2015**	Electromagnetic compatibility (EMC)
■ **EN IEC 62368-1**	Electromagnetic compatibility (LVD)
■ **CE marking**	C E

Manufacturer/Importer

Name : A van Rossem Position/ Title : Product Manager
Place : Republic of China (Taiwan) Date : June 2024

Regulatory Approvals

● **CE Statement**

This product complies with the 2014/30/EU and 2014/35/EU directives, including the following safety and EMC standards:

■ **EN 55032:2015/A1:2020**
  Electromagnetic compatibility (EMC)

■ **EN IEC 61000-3-2:2019/A1:2021**
  Electromagnetic compatibility (EMC)

■ **EN 61000-3-3:2013/A2:2021**
  Electromagnetic compatibility (EMC)

■ **EN 55035:2017/A11:2020**
  Electromagnetic compatibility (EMC)

■ **EN 62368-1:2020+A11:2020**
  Electromagnetic compatibility (LVD) - Safety

● **RoHS Statement**

This product complies with RoHS directive 2011/65/EU and amendment Commission Delegated Directive (EU)2015/863.

■ **IEC 62321-3-1:2013**

■ **IEC 62321-5:2013**

■ **IEC 62321-4:2013+AMD1:2017**

■ **IEC 62321-7-1:2015**

■ **IEC 62321-7-2:2017**

■ **IEC 62321-6:2015**

■ **IEC 62321-8:2017**

● **CE Marking Warning**

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

Installation Steps

A. Desktop installation

Step 1: As shown in picture 1, lay the switch flat on the desktop, and ensure that at least 10cm of space is reserved on both sides of the vent of the switch so that the switch can be well ventilated and cooled.

Wall-mounted installation

Step 1: As shown in picture 2, find the mounting ears and screws from the accessory bag of the machine, then place the switch upright, place the mounting ears to the installation position, and see if the screw holes are aligned properly After confirming the match, use a screwdriver to fix the hanging ears on both sides of the machine with screws.


Picture 1

Left   Right

Picture 2

B. Rack installation

Step 1: Fix the L-shaped mounting brackets on both sides of the switch with the screws provided in the accessories.

Step 2: The mounting brackets are fixed on the guide groove with screws to ensure that the switch is stable and horizontally installed on the rack.

C. Power Connection

1. Connect the powercord to the back of the Switch and turn the power switch on.

LED DEFINITIONS

ID	Off	The ID indicator is disabled and is in default state.
	On	This indicator is used for on-site location. O&M personnel remotely control the ID indicator to turn on or off.
MGMT	On	The ETH Port is link up.
	Off	The ETH Port is link down.
SYS	On	System is normal.
	Flashing	System startup.
Port Indicator	Flashing	Data transmitting.
	Off	The link is down.

EN English

Important Information

- The default IP address: *Please use the CLI mode*
- The content of user's guide and associated software can be downloaded from the website (www.airlive.com)
- The L3D-10XGF26-100GF works with 10G SPF+ and 100G QSFP28 fiber modules. Modules not included.