

## Declaration of Conformity

We, Manufacturer/Importer

**AirLive Technology Corporation**  
 4F, No.132, Lane 235, Baoqian Rd., Xindian Dist.,  
 New Taipei City 23145, Taiwan

Declare that the product

**Unmanaged Multi Gigabit Fiber Switch  
 Ether-8GF**  
**is in conformity with**

In accordance with 2014/30/EU and 2014/35/EU Directive

Clause	Description
■ EN 55032:2015	Electromagnetic compatibility (EMC)
■ EN IEC 62368-1	Electromagnetic compatibility (LVD)

■ CE marking 

### Manufacturer/Importer

Name : A van Rossem Position/ Title : Product Manager  
 Place : Republic of China (Taiwan) Date : November 2022



## Regulatory Approvals

### • CE Statement

This product complies with the 2014/30/EU and 2014/35/EU directives, including the following safety and EMC standards:

- **EN 55032:2015+A11:2020**  
Electromagnetic compatibility (EMC)
- **EN IEC 61000-3-2:2019+A1:2021**  
Electromagnetic compatibility (EMC)
- **EN 61000-3-3:2013+A2:2021+AC:2022-01**  
Electromagnetic compatibility (EMC)
- **EN 55035:2017+A11:2020**  
Electromagnetic compatibility (EMC)
- **EN IEC 62368-1:2020/A11:2020**  
Electromagnetic compatibility (LVD) - Safety


### • CE Marking Warning

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

### • FCC 47 CFR Part 15 Subpart B (Class B), ANSI C63.4:2014

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

**Installation Steps**  
Example (A) Connection



**LED DEFINITIONS**

<b>PWR</b>	Green ON	Power is on and normal.
	Green OFF	The switch is not receiving power.
<b>Link/Act 1~8 SFP</b>	Green ON	The port Status LEDs ON Link Connection, LEDs Blinking Data transmission.
<b>Link/Act RJ-45</b>	Green ON	The port Status LEDs ON Link Connection, LEDs Blinking Data transmission.
	Green OFF	No Connection.
<b>Speed</b>	Orange ON	1Gbps.

**EN** English

**Installation Step:**

1. Remove the switch and accessories from the package.
2. Connect power adapter to the switch. Make sure that Power (PWR) LED is on.
3. Connect your SFP LX/SX module to one of the 8 SFP port of the switch  
Use the Fiber switch as main connection point of other fiber device (see A).
4. Check the Port LED indicator status. When a device is connected SFP/RJ-45 it light on.
5. For more product information visit [www.airlive.com](http://www.airlive.com).